#### **Product sheet**

## **Output connector**



Product Contacts: 6, Female angled connector,


right-turning (the pin and socket insert counter-rotate in right and left turning


models)

Pole

Area M23 Power Series 623 Article number 99 4636 00 06







### You can find the assembly instruction on the next page.

# Technical data

#### **Common values**

Connector Design Connector locking system Termination Wire gauge (mm) Wire gauge (AWG) Cable outlet Upper temperature Lower temperature Female cable connector screw Solder 2.50 mm<sup>2</sup> 14 6 - 10 mm 125 °C -20 °C

#### **Electrical values**

Rated voltage 300 V Rated impulse voltage 2500 V Pollution degree Overvoltage category П Material group Ш Rated current (40°C) 20 A Volume resistivity  $\leq 3 \text{ m}\Omega$ not shielded EMV compliance Degree of protection IP67 > 50 mating cycles Mechanical operation

#### **Material**

 Material of contact
 CuSn (Bronze)

 Contact plating
 Au (Gold)

 Material of contact body
 PBT/PA66

 Material of housing
 CuZn (Brass nickel-plated)

Contacts: 6, Female cable connector, right-turning

#### **Product sheet**

## **Output connector**



Product Contacts: 6, Female angled connector,


right-turning (the pin and socket insert counter-rotate in right and left turning

models)

Pole

Area Article number M23 Power Series 623 99 4636 00 06

### Installation instructions / Mounting cutout



- Kabelverschraubung Pos. 1, Adapter Pos. 2 und Überwurfmutter Pos. 3 auf das Kabel schieben.
- Kabel-Außenmantel 20 mm abisolieren.
- Folie, Füller und innere Isolierungen abschneiden.
- Litzen 3,5 mm abisolieren, verdrillen und verzinnen.
- Litzen an Kontakte löten, crimpen oder schrauben.
- Distanzhülse Pos. 4 einfügen.
- Einsatz Pos. 5 und Distanzhülse Pos. 4 in Einsatzring Pos. 6 einführen. Hierbei ist zu beachten, daß die gewünschte Kodiernut des Einsatzes Pos. 6 in den Kodiersteg eingeführt wird.
- Adapter Pos. 2 Festschrauben auf Anschlag.
- Kabelverschraubung Pos. 1 Festschrauben.

Anzugsdrehmoment für Klemmschraube Kontakteinsatz Pos. 5 mit Schraubkontakten beachten:

- max. 0,1 Nm für Schraubkontakte Steckdurchmesser 1 mm
- max. 0,2 Nm für Schraubkontakte Steckdurchmesser 2 mm

- Push the cable screw connection (1), adapter (2) and coupling nut (3) onto the cable.
- Strip the cable coating by 20 mm.
- Trim foil, filler and inner insulation.
- Strip the single wires by 3.5 mm, twist and tin.
- Solder, crimp or screw the single wires to the contacts.
- Insert the distance shell (4).
- Guide the insert (5) and distance shell (4) into the insert ring (6), mind that the desired coding groove of the insert (6) is pushed into the coding bar.
- Screw the adapter (2) as tight as possible.
- Screw the cable gland (1) as tight as possible.

Please note: torque for clamping screw for contact insert (5) with screw contacts:

- max. 0.1 Nm for screw contacts with mating dia. 1 mm
- max. 0.2 Nm for screw contacts with mating dia. 2 mm

Date: 2015-06-04 - Page 2 of 2